



SCMT4
Las Vegas, USA, August 7-11, 2016

Properties of Alkali-Activated Natural Pozzolan and Fly Ash Mortars: A Comparative Study

Meysam Najimi^{1a}, Nader Ghafouri^{1b}, Brittany Radke^{1c}, Kimberly Sierra^{1d}, and MohammadReza Sharbaf^{1e}

¹*Department of Civil and Environmental Engineering and Construction, University of Nevada Las Vegas, 4505 Maryland Parkway, Las Vegas, Nevada, USA, 89154-4015.*

^{1a}*Email: <najimim@unlv.nevada.edu>*, ^{1b}*Email: <nader.ghafouri@unlv.edu >*,

^{1c}*Email: <radkeb4@unlv.nevada.edu>*, ^{1d}*Email: <sierrak@unlv.nevada.edu>*,

^{1e}*Email: <sharbaf@unlv.nevada.edu>*

ABSTRACT

The study presented herein compares flow, strength and transport properties of natural pozzolan- and fly ash-based alkali-activated mortars. To this end, several mixtures were made having natural Pozzolan or fly ash as a binder and sodium hydroxide with different concentrations of 2.5, 5, 7.5, 10 and 12.5M as alkaline activator. The produced mortar samples were sealed-cured for 3 hours at 60°C, and then demolded and sealed-cured at 80°C till time of testing. Multiple tests were conducted on alkali-activated mortars including flow spread, compressive strength, flexural strength, elastic modulus, absorption, and rapid chloride migration. These tests were also conducted on Portland cement mortars to compare performance of alkali-activated to that of Portland cement mortars. The results of this study revealed that natural Pozzolan can be activated and perform to the same level of fly ash. However, the rate of activation was slower and the minimum level of alkaline concentration for a proper activation was higher for natural Pozzolan than fly ash. While alkali-activated mortars displayed considerably lower strength than those of Portland cement mortars, the studied mortars activated with sodium hydroxide molarities of 7.5 to 12.5M produced results suitable for structural applications. The transport properties of alkali-activated mortars having high NaOH molarity were similar to that of Portland cement mortars.

INTRODUCTION

In recent decades, climate change, due to greenhouse gas emissions, has become a major global issue. Higher temperatures, changing landscapes, rising seas, increased risk of drought, fire and floods, wildlife at risk, stronger storms and increased storm damages, and economic losses are only examples of climate change impact.

One of the main industries responsible for greenhouse gas emissions is cement and concrete industry. Production of Portland cement (PC), as a main ingredient of concrete, contributes to about 7% of world's total carbon dioxide gas emission [Huntzinger et al. 2009; Pacheco-Torgal et al. 2012]. The desire to

reduce CO₂ emission of cement production has given impetus to search for new binders including alkali-activated binders, calcium aluminates cements, calcium carbonate cements, magnesium oxy-carbonate cements, Bellite-calcium sulphoaluminate-ferrite cements, and partially pre-hydrated C-S-H based binders [Pacheco-Torgal et al. 2008; Ismail et al. 2014]. Although far more research is needed for these alternative binders, several researchers suggested that alkali-activated binders may have the potential to lead the transition to the cement of the future [Palomo et al. 1999; Pacheco-Torgal et al. 2008 and 2012; Shi et al. 2011; Ismail et al. 2014]. Accordingly, a great portion of research has recently been devoted on assessment and development of alkali-activated materials.

Fly ash is one of the most popular choices as the starting ingredient of alkali-activated materials. In recent decades, several studies have been dedicated to alkali activation of fly ash. It has been proven that strong and durable mixtures can be made by use of alkali-activated fly ash as the main binder [Fernandez-Jimenez et al. 2006; Pacheco-Torgal et al. 2008]. Various models have also been proposed describing the activation process of fly ash-based geopolymers [Glukhovskiy 1994; Fernandez-Jimenez et al. 2005; Palomo et al. 2005; Duxson et al. 2007; Shi et al. 2011].

Natural Pozzolan is another source of aluminosilicates that has similar characteristics to fly ash. Unlike fly ash, the research on alkali-activation of natural Pozzolans has been very limited. Figure 1 compares the number of publications on alkali-activation of natural Pozzolan and fly ash. It can be seen that the research on alkali-activated natural Pozzolan or natural Pozzolan-based geopolymer hardly reaches 2% of the total studies conducted on alkali-activated fly ash and fly ash-based geopolymer. Figure 2 shows that while it's estimated that about 5% of the solid surface of the earth is covered by volcanic or effusive rocks (according to Lorenz (1985)), only a few studies have been carried out by a few researchers; mainly in the Middle East [Bondar et al. 2011, 2012; Lemouagna et al. 2011; Haddad and Alshbuol 2016]. Moreover, not only the research on activation of natural Pozzolans is limited, there has not been any study to compare properties of natural Pozzolan- and fly ash-based geopolymers.

This study aims to (1) investigate if natural Pozzolan can be successfully activated to meet the desired performance, (2) examine whether natural Pozzolan can be activated to the same level of fly ash by comparing properties of alkali-activated natural Pozzolan and fly ash mortars, and (3) compare properties of alkali-activated mortars with those of Portland cement mortars. To this end, a total of ten natural Pozzolan and fly ash mortars activated with sodium hydroxide concentrations of 2.5, 5, 7.5, 10 and 12.5M, and two reference Portland cement mortars were prepared and their fresh and hardened properties evaluated.

EXPERIMENTAL PROGRAM

Materials

The materials used in this study included natural Pozzolan and fly ash as the binder, sodium hydroxide solution as the alkaline activator, and fine aggregates. Type V Portland cement was also used to make reference Portland cement mortars. The chemical properties of the used binders are presented in Table 1. Table 2 documents the chemical and physical requirements of natural Pozzolan and fly ash based on ASTM C618. As can be seen, the used natural Pozzolan and fly ash contained 78.4 and 87.3% of Pozzolan oxides (silica, alumina, and iron oxides), respectively, well beyond 70% requirement of ASTM C618. The used fly ash, however, contained more Pozzolan oxides than the used natural Pozzolan. The silica-to-alumina ratio of natural Pozzolan was significantly higher than that of fly ash. This ratio was 8.1 for natural Pozzolan; three times as much as that of fly ash (2.7). The calcium oxide content was low for both natural Pozzolan and fly ash (3.2 and 4.7% for natural Pozzolan and fly ash, respectively), indicating that the used aluminosilicate sources were not cementitious on their own. The fine aggregates used in this study had an oven-dry specific gravity of 2.76, absorption of 0.81%, and fineness modulus of 2.64.




Figure 1. Evolution of accumulated number of publications in Scopus database searched by different keywords in the “article title, abstract, keywords” section




Figure 2. The global map of volcanoes (red triangular) [Sam 2015] and the countries conducted research on alkali-activated natural Pozzolans (black circles)

Sodium hydroxide solutions were made by dissolving NaOH pellets in distilled water. In order to make a liter of solution with molarities of 2.5, 5, 7.5, 10, and 12.5M; 100, 200, 300, 400, and 500g of NaOH pellets were dissolved in enough water to produce one total liter of solution, respectively. The amounts of water and NaOH used to make a liter of solution are shown in Table 3. NaOH pellets were added in incremental amounts and underwent vigorous swirling to ensure complete dissolution throughout the distilled water. The NaOH solutions were allowed to cool down in a water bath before being added to the mortar mixture.

Mixture proportion

Table 3 presents the mixture proportion of the selected alkali-activated mortars. This Table includes 5 different mixtures for each binder using sodium hydroxide concentrations of 2.5, 5, 7.5, 10, and 12.5M, and an activator (solution hydroxide solution)-to-binder ratio of 0.50 (except for mix N12.5 which has a ratio of 0.54). For these mixtures, the fine aggregate-to-binder ratio was kept constant at 2. This ratio was chosen based on a preliminary study conducted on different fine aggregate-to-binder ratios of 1.5, 2, 2.5, and 3. Table 3 also includes two reference Portland cement mortars which were made for comparison purposes. Mixture Reference I was designed in accordance with ASTM C109 (2002) having water-to-cement ratio of 0.485 and fine aggregate-to-cement ratio of 2.75. Mixture Reference II was designed by use of similar water-to-cement ratio of 0.485 but different fine aggregate-to-cement ratio of 2.

Sample preparation

A single axis industrial pan mixer was used to prepare fresh mortars. Mortar mixtures were prepared by adding one-half of the NaOH solution in the mixing bowl, followed by carefully adding in the binders and fine aggregates. It was found that adding the NaOH solution first allowed for easier and more thorough mixing. The fine aggregates, binder, and NaOH solution were mixed for two minutes on the slow speed (140 ± 5 r/min according to ASTM C305 (ASTM 1999)). The remaining one-half of the NaOH solution was added and the mortar was mixed on the slow speed for an additional two minutes before turning on medium speed (285 ± 10 r/min according to ASTM C305 (ASTM 1999)) for thirty seconds to ensure that the materials were uniformly mixed. Similar method of mixing was used for reference mortars with the exception that all the water was charged to the mixer first. Fresh mortars were tested for flow according to ASTM C1437 (ASTM 2001) before cube, disk and beam-shaped specimens were cast for assessments of compressive strength, absorption, rapid chloride migration and flexural strength.

Alkali-activated mortar samples were sealed-cured initially at 60°C for 3 hours in an oven prior to demolding. Samples were then removed from the molds and sealed-cured at 80°C till time of testing. The sealed curing was provided by wrapping samples in plastic to retain moisture within the sample. Reference Portland cement mortar samples were left in laboratory for a day before demolding. They were then demolded and transferred to the curing room (ambient temperature and 100% relative humidity). They were kept in the curing room till testing time.

Table 1. Chemical composition of the used binders

Chemical analysis, %	Cement	Natural Pozzolan	Fly ash
Calcium oxide (CaO)	63.31	3.2	4.67
Silica (SiO ₂)	20.42	68.8	59.93
Alumina (Al ₂ O ₃)	4.25	8.5	22.22
Iron oxide (Fe ₂ O ₃)	4.05	1.1	5.16
Magnesium oxide (MgO)	2.0	--	
Sodium oxide (Na ₂ O)	0.04	2.6	1.29*
Potassium oxide (K ₂ O)	0.69	3.9	
Sulfur trioxide (SO ₃)	2.98	0.1	0.38
Loss on ignition	2.5	3.7	0.32

* Total alkali, as Na₂O

Table 2. Chemico-physical properties of natural Pozzolan and fly ash according to ASTM C618 (2012)

Requirements		Class N	Class F	Natural Pozzolan results	Fly ash results
Chemical requirements	SiO ₂ +Al ₂ O ₃ +Fe ₂ O ₃ , %	min, 70.0	min, 70.0	78.4	87.31
	Sulfur trioxide (SO ₃), %	max, 4.0	max, 5.0	0.1	0.38
	Moisture content, %	max, 3.0	max, 3.0	0.7	0.04
	Loss on ignition, %	max, 10.0	max, 6.0	3.7	0.32
Physical requirements	Amount retained when wet-sieved on 45 µm sieve, %	max, 34	max, 34	13.5	21.2
	¹ Strength activity index, at 7 days, percent of control	min, 75	min, 75	85	83
	¹ Strength activity index, at 28 days, percent of control	min, 75	min, 75	92	79
	Water requirement, percent of control	max, 115	max, 105	103	97
	Autoclave expansion or contraction, %	max, 0.8	max, 0.8	0	-0.02
	Specific gravity	--	--	2.29	2.31

¹Note that, the activity index is determined based on ASTM C311 (2013) by replacing 20% of cement with natural Pozzolan or fly ash.

Table 3. Mixture proportions and flow of alkali-activated and Portland cement mortars.

Alkali-activated mortars								
Mix id	Activator Molarity	Fly ash (g)	Natural pozzolan (g)	Fine Aggregate (g)	Activator Solution (g)	Weight per liter of solution (g)		Flow (cm)
						Water	Sodium Hydroxide	
N2.5	2.5	0	4740.3	9480.6	2370.2	989.1	100	9.9
F2.5		4740.3	0					15.2*
N5	5	0	4740.3	9480.6	2370.2	973.9	200	6.5
F5		4740.3	0					15.2*
N7.5	7.5	0	4740.3	9480.6	2370.2	950.3	300	5.7
F7.5		4740.3	0					12.1
N10	10	0	4740.3	9480.6	2370.2	903.4	400	3.7
F10		4740.3	0					11.8
N12.5**	12.5	0	4740.3	9480.6	2559.8**	858.8	500	3.5
F12.5		4740.3	0		2370.2			8.5
Reference Portland cement mortars								
Mix id	Cement (g)		Fine Aggregate (g)		Water (g)		Flow (cm)	
Reference I	4740.3		13035.8		2299		15.2	
Reference II	4740.3		9480.6		2299		15.2*	

* These flows were higher, but the test apparatus only allowed for flow measurement of up to 15.2 cm.

** As flow of mix N12.5 was extremely low using activator-to-binder ratio of 0.5 (impractical to cast), this ratio was increased to 0.54 for this mixture.

Testing

The flow test was conducted according to ASTM C1437 (ASTM 2001) upon batching.

Compressive strength test was performed on 5 cm cube samples in a procedure similar to ASTM C109 (ASTM 2002b).

The flexural strengths of the 5×5×20 cm beams were measured in accordance with ASTM C78 (ASTM 2002a). Four beams were tested for each mixture. Strain gauges were attached to the extreme tension side of the beams to determine strain and modulus of elasticity.

Absorption and volume of permeable voids were measured according to ASTM C642 using disks with diameter of 10 cm and height of 5 cm. Similar size disks were used for measurement of rapid chloride migration in accordance with NT BUILD 492 (1999).

RESULTS AND DISCUSSIONS

Flow

The results of the flow test are presented in Table 3. As can be seen, the flow of alkali-activated natural Pozzolan mortars were significantly lower than those of alkali-activated fly ash mortars. On average, the flow of natural Pozzolan-based mortars was 54.5% lower than that of fly ash-based mortars. This difference could have been even higher if the flow table allowed for measurements of more than 15.2 cm and mix N12.5 could be mixed with activator-to-binder ratio of 0.50. The observed difference can be related to the finer particle size of natural Pozzolan as compared with fly ash (See Figure 3). The median particle size (50% passing size) of natural Pozzolan was almost 15.8 micron which was lower than that of fly ash (20 micron). Table 2 also shows that the used natural Pozzolan had higher water demand than the used fly ash. The finer particle size and higher water demand of natural Pozzolan led to lower flow of alkali-activated natural Pozzolan mortars than companion fly ash mortars.

The flow of both types of alkali-activated mortars was lower than that of Portland cement mortars. On average, the flow of natural Pozzolan- and fly ash-based mortars were 61 and 17% lower than that of Portland cement mortars, respectively. Some of the fly ash-based mortars (2.5 and 5M), however, had a similar flow to those of the reference mortars.

The flow of alkali-activated mortars decreased when NaOH concentration increased. The decreases in flow of natural Pozzolan-based mortars were 34, 12, and 35%, when molarity of activator increased from 2.5 to 5, 5 to 7.5, and 7.5 to 10, respectively. In case of alkali-activated fly ash mortars, the flow reduced by 20, 2.5, and 28% when molarity increased from 5 to 7.5, 7.5 to 10, and 10 to 12.5, respectively. An explanation for this trend can be due to the amount of alkaline and water in the prepared solution. An increase in the activator concentration allowed for more sodium hydroxide pellets and less free water for a given volume, resulting in the reduction of flow spread.

Compressive strength

Table 4 documents the results of the compressive strength test for all the tested mixtures. Overall, 2.5M was insufficient for activation of either natural Pozzolan or fly ash resulting in considerably low strengths. Higher sodium hydroxide concentration was required for proper activation of natural Pozzolan as compared with fly ash. Considering 20 MPa as a minimum strength requirement for structural applications, at least 7.5M was required for activation of natural Pozzolan, whereas 5M was sufficient for fly ash-based mortars. These observations can be related to the minimum alkalinity required to break the bonds of the starting material. When alkalinity of the system was low, the ionic strength generated in the binder-activator system was not high enough to properly hydrolyze the silicon and aluminum present in the binder [Pacheco-Torgal et al. 2015]. This, in turn, resulted in low strengths. In addition, Si-O bonds

are stronger than Al-O bonds, thus requiring stronger activator to break their bonds. As silica/alumina was higher for natural Pozzolan than fly ash (Si-O/Al-O bonds of natural Pozzolan > Si-O/Al-O bonds of fly ash), higher alkaline concentration was needed to break the bonds for natural Pozzolan than fly ash.




Figure 3. Particle size distribution of fly ash and natural Pozzolan

Alkali-activated fly ash mortars developed higher strengths than alkali-activated natural Pozzolan mortars prepared with lower NaOH molarities (5 and 7.5M). However, the gap in strength between the two alkali-activated mortars narrowed once high NaOH concentrations (i.e., 10 and 12.5M), were used. The 7-day strengths of natural Pozzolan contained mortars were 39 and 23% lower than that of fly ash contained mortars activated using NaOH molarities of 5 and 7.5M, respectively. The strength of 10M natural Pozzolan contained mortar was slightly higher than that of 10M fly ash contained mortar (only 5%). This observation can also be attributed to the minimum level of alkaline needed to break the bonds of the starting material. When alkalinity was more than the abovementioned levels, the activator was able to break Si-O and Al-O bonds for both fly ash and natural Pozzolan even when it could take more time to break the stronger bonds (Si-O) than the weaker bonds (Al-O). In case of 12.5M, natural Pozzolan-based mortar developed 11% lower strength than fly ash-based mortar. This difference was related to the difference in activator-to-binder ratio. Strength of 12.5M alkali-activated natural Pozzolan mortar could have been closer to alkali-activated fly ash mortar, should the mixture had been prepared with an activator-to-binder ratio of 0.5 (0.54 was used due to flow requirement).

It should be also added that overall, the strength development was faster in fly ash-based mortars than natural Pozzolan-based mortars. This finding can be seen in Figure 4 which shows the ratios of 1 day-to-7 days compressive strengths and 3 days-to-7 days compressive strengths. Alkali-activated natural Pozzolan mortars gained 78, 43, 36, 30, and 34% of their 7-day strength in 1 day and 92, 78, 81, 70, and 78% in 3 days for molarities of 2.5, 5, 7.5, 10, and 12.5, respectively. For similar molarities, alkali-activated fly ash mortars developed 40, 40, 67, 66, and 78% of their 7-day strength in 1 day and 91, 86, 99, 91 and 93% in 3 days, respectively. This observation can also be related to the difference in chemical composition of natural Pozzolan and fly ash (different amounts of silica and alumina). Previous studies showed that the absence of sufficient amounts of aluminum could retard the conversion of Gel 1 (aluminum-rich, Si/Al~1) into Gel 2 (silicon-rich, Si/Al~2), affecting the strength of the resulting product [Pacheco-Torgal et al. 2015]. As Gel 2 is responsible for majority of mechanical strength, hindering its formation could be the reason that natural Pozzolan gained its intrinsic strength slower than fly ash.

It can also be seen that increases in molarity of activator led to improvements in compressive strength. On average, the 7-day compressive strength of alkali-activated natural Pozzolan mortars increased by 6.6, 8 and 11.4 MPa, when NaOH concentration increased from 2.5 to 5, 5 to 7.5, 7.5 to 10M, respectively. Similar increases in molarity of activator led to averagely 15.3, 6.1, and 3.7 MPa improvements for the alkali-activated fly ash mortars, respectively. The observed improvements can be related to the greater solubility of aluminosilicate in higher NaOH concentration [Khale and Chaudhary 2007]. Since one of the main steps of geo-polymerization process is the breakdown of aluminosilicates (Si-O-Si and Al-O-Si bonds) in alkaline environment, higher concentrations led to increased breakdowns. As more aluminosilicates bonds broke down, there were further opportunities for hydrates to be formed, thus increasing the compressive strength.

Both natural Pozzolan- and fly ash-based mortars developed considerably lower strength than those of reference mortars. The ultimate compressive strength (7-day) of 12.5M alkali-activated mortars were averagely 41 and 51% lower than 28-day compressive strength of reference I and reference II mixtures, respectively. Although this finding shows that partial use of sodium silicate as an alkaline activator could be inevitable to achieve similar strength to those of Portland cement mixtures, the produced strengths using high NaOH molarities (7.5M and above) were sufficient for structural applications.

Table 4. Compressive strength of alkali-activated and reference mortars (MPa)

	NaOH Concentration (M)	Age (days)	Natural Pozzolan-based mortars	Fly ash-based mortars
Alkali-activated mortars	2.5	1	4.6	2.1
		3	5.4	4.8
		7	5.9	5.3
	5	1	5.4	8.3
		3	9.7	17.8
		7	12.5	20.6
	7.5	1	7.4	17.8
		3	16.5	26.5
		7	20.5	26.7
	10	1	9.4	20.0
		3	22.3	27.5
		7	31.9	30.4
	12.5	1	10.4	27.2
		3	24.1	32.2
		7	30.8	34.7
Reference Portland cement mortars		Age (days)	Reference I	Reference II
		3	37.8	42.8
		7	46.9	52.3
		28	59.3	71.5




Figure 4. Strength development rate of alkali-activated mortars, (a) 1 day-to-7 days compressive strength ratio, (b) 3 days-to-7 days compressive strength ratio

Flexural strength

Modulus of rupture of the studied alkali-activated mortars was evaluated on the 7-day sealed oven-cured beams. Strain gauges were attached at samples' extreme tension side to measure flexural strains. The obtained stress-strain curve was used to calculate modulus of elasticity of the studied mortars. The modulus of rupture and elastic modulus of alkali-activated mortars are documented in Table 5. Overall, the flexural strength and modulus of elasticity of fly ash- and natural Pozzolan-based mortars were in the same range. Both of these properties increased with increases in NaOH concentration. Modulus of rupture of alkali-activated natural Pozzolan mortars increased by 108, 123, 15, and 20% when molarities of solution increased from 2.5 to 5, 5 to 7.5, and 7.5 to 10, and 10 to 12.5, respectively. These increases were 210, 35, 5, and 13% for modulus of elasticity, respectively. Increases in molarity of solution from 5 to 7.5, 7.5 to 10, and 10 to 12.5 led to 32, 65, and 33% improvements in modulus of rupture, and 13, 13, and 30% increases in modulus of elasticity of alkali-activated fly ash mortars, respectively.

The flexural strength-to-compressive strength ratio was also calculated and the results are presented in Table 5. In general, this ratio was higher for natural Pozzolan contained mortars than fly ash contained mortars. It varied in the range of 0.22 to 0.30 and 0.16 to 0.27 for alkali-activated natural Pozzolan and fly ash mortars, respectively.

Transport properties

Initially, absorption, rapid chloride migration and rapid chloride penetration tests were considered for the purpose of this study. It was found that rapid chloride penetration test (RCPT) gives misleadingly high results for this type of alkali-activated materials. Therefore, this section compares only absorption and rapid chloride migration of alkali-activated natural Pozzolan mortars with alkali-activated fly ash mortars and reference Portland cement mortars. These tests were conducted on 7-day alkali-activated and 28-day Portland cement mortar samples.

Absorption

ASTM C642 was used to determine the absorption and volume of permeable voids of the studied alkali-activated mortars. Table 6 presents the results of this test. It can be seen that alkali-activated mortars with low molarities exhibited higher absorption and volume of permeable voids than reference mortars, whereas contrary was found for high molarities. Similar to the strength properties, nearly 7.5M sodium hydroxide was needed for alkali-activated mortars to reach a satisfactory performance (almost same absorption and volume of permeable voids to that of reference Portland cement mortars. Using NaOH

concentrations of 10 and 12.5M, alkali-activated natural Pozzolan mortars had lower absorption and volume of permeable voids than alkali-activated fly ash and reference Portland cement mortars.

Figure 5 also shows the absorption of alkali-activated mortars for different molarities. As can be seen, there was an almost linear trend in the results of absorption with increases in molarity of activator. Absorption of natural Pozzolan contained mortars reduced by 17, 26, 49, and 40% when molarity increased from 2.5 to 5, 5 to 7.5, 7.5 to 10, and 10 to 12.5M, respectively. Similarly, volume of permeable voids significantly reduced with increases in NaOH concentration. For similar increases in molarity of activator, volume of permeable voids of natural Pozzolan-based mortars decreased by 11, 24, 45 and 6%, respectively. In case of fly ash-based mortars, increases in NaOH concentration from 5 to 7.5, 7.5 to 10, and 10 to 12.5M led to 13, 20, and 18% improvement in absorption, and 12, 5, and 4% reduction in volume of permeable voids, respectively. Higher hydroxide concentration resulted in greater alkali-activation and a more compact matrix with less voids to allow for moisture penetration (decreased absorption).

Table 5. Flexural strength test results

Mix id	Modulus of Rupture (MPa)	Modulus of Elasticity (GPa)	Modulus of Rupture/Compressive Strength
N2.5	1.33	4.33	0.23
F2.5	Not measured	Not measured	--
N5	2.77	13.43	0.22
F5	3.30	13.87	0.16
N7.5	6.17	18.16	0.30
F7.5	4.35	15.71	0.16
N10	7.07	19.15	0.22
F10	7.16	17.80	0.24
N12.5	8.49	21.55	0.28
F12.5	9.52	23.15	0.27

Table 6. Results of absorption test

Mix id	Absorption after immersion (%)	Volume of Permeable voids (%)
N2.5	12.40	25.84
F2.5	Not measured	Not measured
N5	10.33	22.95
F5	10.18	16.42
N7.5	7.70	17.47
F7.5	8.88	14.51
N10	3.94	9.54
F10	7.10	13.85
N12.5	2.38	9.01
F12.5	5.86	13.32
Reference I	6.70	15.44
Reference II	7.53	16.98




Figure 5. Absorption of alkali-activated mortars

Rapid chloride migration test

Table 7 documents results of rapid chloride migration test on alkali-activated and reference mortars. It can be seen that chloride penetration, presented as diffusion coefficient and penetrated depth per volt. hour, considerably decreased by increases in molarity of sodium hydroxide. The rate of penetrated chloride for natural Pozzolan-based mortars reduced by 38, 56, 39, and 19%, when molarity of solution increased from 2.5 to 5, 5 to 7.5, 7.5 to 10, and 10 to 12.5M, respectively. In case of fly ash-based mortars, this rate reduced by 8, 13, and 20% when molarity increased from 5 to 7.5, 7.5 to 10, and 10 to 12.5M, respectively.

Similar to the other tested properties, natural Pozzolan required higher molarity to reach an acceptable performance as compared with fly ash. It can be seen that 5M fly ash-based mortar displayed almost similar results to those of 7.5M natural Pozzolan-based mortar. For high molarities, performance of alkali-activated natural Pozzolan and fly ash mortars were almost similar. It was also noted that only 12.5M alkali-activated mortars showed close performance to those of Portland cement mortars.

Table 7. Results of rapid chloride migration test

Mixture id	Chloride diffusion coefficient ($\times 10^{-12}$ m ² /s)	Rate of chloride penetration (mm/Vh)
N2.5	194.77	0.538
F2.5	Not measured	Not measured
N5	112.56	0.331
F5	32.31	0.0986
N7.5	41.33	0.144
F7.5	34.17	0.0909
N10	21.38	0.088
F10	26.76	0.0795
N12.5	15.63	0.071
F12.5	19.58	0.0634
Reference I	16.05	0.0468
Reference II	16.30	0.0475

CONCLUSION

Based on the results of this study, the following conclusions can be drawn:

- Overall, natural Pozzolan and fly ash proved to be a viable replacement for Portland cement. While the studied alkali-activated mortars yielded considerably lower strength than those of Portland cement mortars, majority of them produced compressive strengths well beyond the required structural compressive strength of 20 MPa. The transport properties of alkali-activated mortars having high NaOH molarity were similar to that of Portland cement mortars.
- The flow of alkali-activated natural Pozzolan mortars was significantly lower than those of alkali-activated fly ash and Portland cement mortars. The flow of the studied alkali-activated mortars reduced with increases in molarity of sodium hydroxide solution.
- The minimum amount of sodium hydroxide concentration for proper activation was higher for natural Pozzolan mortars than fly ash mortars. While 5M alkali-activated fly ash mortars developed enough strength for structural applications, 7.5M of sodium hydroxide solution was needed for natural Pozzolan mortars to reach the same level of strength. A similar trend was observed for the transport properties of the studied alkali-activated mortars.
- For low molarity sodium hydroxide solutions (5 and 7.5M), strength of alkali-activated natural Pozzolan mortars were lower than those of alkali-activated fly ash mortars, whereas high molarity alkali-activated mortars (10 and 12.5M) produced similar results.
- The strength development rate was faster in alkali-activated fly ash mortars than alkali-activated natural Pozzolan mortars.
- Use of higher NaOH concentrations led to improved compressive strength, flexural strength, elastic modulus, absorption, volume of permeable voids, and depth of penetrated chloride of the studied alkali-activated mortars.

ACKNOWLEDGEMENTS

This study was partially funded by NSF Grant # EPS-0814372 “Nevada Infrastructure for Climate Change Science, Education, and Outreach.” Authors would like to thank the National Science Foundation for their support. Thanks are also extended to the Nevada Cement Company for donating natural Pozzolans used in this study.

REFERENCES

- ASTM C109 (2002) Standard Test Method for Compressive Strength of Hydraulic Cement Mortars. ASTM, Philadelphia.
- ASTM C1437 (2001) Standard Test Method for Flow of Hydraulic Cement Mortar. ASTM, Philadelphia.
- ASTM C305 (1999) Standard Practice for Mechanical Mixing of Hydraulic Cement Pastes and Mortars of Plastic Consistency. ASTM, Philadelphia.
- ASTM C311 (2013) Standard Test Methods for Sampling and Testing Fly Ash or Natural Pozzolans for Use in Portland-Cement Concrete. ASTM, Philadelphia.
- ASTM C618 (2012) Standard Specification for Coal Fly Ash and Raw or Calcined Natural Pozzolan for Use in Concrete. ASTM, Philadelphia.
- ASTM C642 (2013) Standard Test Method for Density, Absorption, and Voids in Hardened Concrete. ASTM, Philadelphia.

- ASTM C78 (2002) Standard Test Method for Flexural Strength of Concrete (Using Simple Beam with Third-Point Loading). ASTM, Philadelphia.
- Bondar D, Lynsdale CJ, Milestone NB, Hassani N (2012) Oxygen and chloride permeability of alkali-activated natural Pozzolan concrete. *ACI Materials Journal* 109(1):53-62.
- Bondar D, Lynsdale CJ, Milestone NB, Hassani N, Ramezaniapour AA (2011a) Effect of type, form, and dosage of activators on strength of alkali-activated natural pozzolans. *Cement and Concrete Composites* 33:251-260.
- Bondar D, Lynsdale CJ, Milestone NB, Hassani N, Ramezaniapour AA (2011b) Engineering properties of alkali-activated natural Pozzolan concrete. *ACI Materials Journal* 108(1):64-72.
- Duxson, P., Fernandez-Jimenez, A., Provis, J.L., Lukey, G.C., Palomo, A. and van Deventer, J.S.J. (2007a) 'Geopolymer technology: the current state of the art', *J Mat Sci*, 42(9), 2917-2933.
- Fernandez-Jimenez A., Palomo A. and Alonso M.M. (2005b), 'Alkali activation of fly ashes: mechanisms of reaction', in *Congress of Non-Traditional Cement and Concrete II*, Ed. V. Bilek and Z. Kersner, Brno University of Technologie, 1-12.
- Fernandez-Jimenez, A., Palomo, A. and Lopez-Hombrados, C. (2006) Engineering properties of alkali-activated fly ash concrete, *ACI Mater Journal*, 103(2), 106-112.
- Glukhovskiy V.(1994) Ancient, modern and future concretes, *First Inter. Conf. Alkaline Cements and Concretes*, Kiev, Ukraine, 1, 1-8.
- Haddad R.H., Alshbuol O. 2016. Production of geopolymer concrete using natural pozzolan: A parametric study. *Construction and Building Materials* 114, 699–707.
- Huntzinger, D.N. & Eatmon, T.D. 2009. A life-cycle assessment of Portland cement manufacturing: comparing the traditional process with alternative technologies. *Journal of Cleaner Production*, 17, 668-675.
- Ismail I., Bernal S.A., Provis J.L., Nicolas R.S., Hamdan S., van Deventer J.S.J. 2014. Modification of phase evolution in alkali-activated blast furnace slag by the incorporation of fly ash. *Cement and Concrete Composites* 45, 125-135
- Khale D., Chaudhary R. (2007) Mechanism of geopolymerization and factors influencing its development: a review. *Journal of Materials Science* 42:729-746.
- Lemougna PN, MacKenzie KJD, Melo UFC (2011) Synthesis and thermal properties of inorganic polymers (geopolymers) for structural and refractory applications from volcanic ash. *Ceramics International* 37(8):3011-3018.
- Lorenz, W., 1985 The use of volcanic rocks as construction raw material, *Natural Resources and Development*, 22, 7-24.
- NT BUILD 492 (1999) Concrete, mortar and cement-based repair materials: chloride migration coefficient from non-steady-state migration experiments. *NORDTEST*.
- Pacheco-Torgal F, Labrincha J, Leonelli C, Palomo A, Chindaprasit P (2015) *Handbook of Alkali-Activated Cements, Mortars and Concretes*. Elsevier, Woodhead publishing series in civil and structural engineering.
- Pacheco-Torgal F., Castro-Gomes J., Jalali S. 2008. Alkali-activated binders: A review: Part 1. Historical background, terminology, reaction mechanisms and hydration products. *Construction and Building Materials* 22(7), 1305–1314.

- Pacheco-Torgal, F., Abdollahnejad, Z., Camões, A.F., Jamshidi, M. & Ding, Y. 2012. Durability of alkali-activated binders: A clear advantage over Portland cement or an un-proven issue?. *Construction and Building Materials*, 30, 400-405.
- Palomo A, Grutzeck MW, Blanco MT (1999) Alkali-activated fly ashes A cement for the future. *Cement and Concrete Research* 29:1323–1329.
- Palomo A., Fernandez-Jimenez A. and Kovalchuk G., (2005), Some key factors affecting the alkali activation of fly ash, 2nd International Symposium of Non-Traditional Cement and Concrete, Brno, Czech Republic.
- Sam (2015) “Why do some volcanoes erupt after being dormant?” <<http://samanthagouldson.com/why-do-some-volcanoes-erupt-after-being-dormant-2/>>
- Shi C., Fernandez-Jimenez A. and Palomo A., (2011) New cements for the 21st century: the pursuit of an alternative to Portland cement, *Cem Concr Res*, 41, 750-763.